




# eDriver Logs® ELD

## Driver Portal

Through the eDriver Logs ELD driver portal, drivers have access to functions such as resolving conflicts and editing, certifying, and printing their logs. With ELD, all drivers are given access to the driver portal. Drivers should contact their administrator if they are unable to sign in to the portal.

To access the ELD Driver Portal, Navigate to the PeopleNet Fleet Manager™ login page (<https://www.pfmlogin.com/pfm-main/authentication/login>) and click on the **ELD Driver Portal Login** link in the lower left of the page.

● DRIVER LOGIN LINK



## HOURS OF SERVICE FEATURES

When the driver logs in, they will be presented with a **Change My Status** option and a count of log days that require certification. Hover over the **HOS** menu to view other available options.

### Change My Status

Drivers can use this page to change their status from Off Duty to On Duty or from On Duty to Off Duty. **Please note: this does not replace properly signing out of a device.** If the driver's current status is an automatic (ELD-recorded) Driving event, they will not be permitted to change their status on the portal until the device has updated the PeopleNet Fleet Manager with the end of the drive.

If the driver forgot to sign out on the device at the end of their shift, they must first return to the vehicle and sign out, then allow the device to communicate that status change to the host before making any log edits on the driver portal. Once they are signed out of the device and their logs on the portal show their current status as off duty, then the driver can safely edit their log as needed.

Welcome, Driver One!

**Open Status:** OFF  
**Start Time:** 9/11/2017 1:40 PM CDT

[Change My Status](#)

## Status change for Driver One on 11/1/2017 CDT

\* indicates a required field.

Open Status: ON  
Start Time: 10/15/2017 8:15 PM CDT  
Change My Status To: \*   
City: \*   
State / Province: \*

## Conflicts Report

The Conflicts Report allows the driver to view and address any conflicts on their logs, such as a missing location or missing odometer. Change the date range of the report by clicking the [...] button next to the date to bring up a calendar. Select a start and end date, then click **View**. If there are any conflicts, click the date of the conflict to be taken to the log to review and correct the issue.

[Help](#) [Sign Out](#)  
QATestOrg / Driver Five  
v9.1.4



### Conflicts Report

HOME HOS > SETTINGS >

Dates: 8/14/2019 [...] to 8/21/2019 [...]

[View](#)

Driver Log Conflicts for Five, Driver from 8/14/2019 to 8/21/2019

Driver	Home Terminal	Date	Conflict
Five, Driver	PeopleNet	8/15/2019	Missing Location

Once on the Driver Log page, scroll down into the details and locate the event with the conflict. In the example below, the event has a missing location. Click the **pencil** icon on the left to view the event details. Enter or update any missing or incorrect information, enter a **Reason for Change**, and click **Save**. Click **Help** for further assistance if needed.

ON 44 Automatic Active 8:45 AM 8:55 AM Location Pending 3100B835A7E5A300 N/A N/A Missing Location

PENCIL ICON

DETAILS

CONFLICT

# Driver Logs

The **Driver Logs** page allows you to view, edit, and certify your logs. Per regulation, logs are available in eDriver Logs ELD for six months. Logs older than six months will be purged from the system daily.

The **Driver Logs** page displays your driver, carrier, and terminal information, the graph grid, your resources such as trailers and vehicles, and your log event details.

Use the **Date** selection field or click **Previous Day** or **Next Day** to navigate among your daily logs. If you use the date selection field, click **View** to display your log for the selected date. Click **Print** to generate a PDF file of your log for the day currently displayed. Click **Certify** to certify your log.



[Help](#) [Sign Out](#)

## Driver Logs

[HOME](#) [HOS](#) [SETTINGS](#)

Date: 9/18/2017 [...](#) [< Previous Day](#) [Next Day >](#)

[View Logs](#) [Print](#)

### Certified

Record Date: 9/18/2017 CDT  
 Time Zone Offset: UTC-05:00  
 24-Hour Starting Time: 12:00 AM  
 Certified by: Driver One  
 on 9/25/2017 12:50 PM CDT


Carrier: QATestOrg  
 USDOT Number: -  
 4400 Baker Road

Home Terminal: PeopleNet  
 4400 Baker Road  
 Minnetonka, MN 55343

Minneapolis, MN 55434

Driver: One, Driver  
 Driver ID: sgoss  
 Multiday Basis: 7 Days  
 License State: MN  
 License Number: SGOSS  
 ELD Provider: N/A  
 ELD Registration ID: N/A  
 ELD Identifier: N/A

### Active Log [View Proposed](#)



### Vehicle IDs / VINs Total Distance Driven Today: 0 mi (0 km)

6026221

### Resources [Edit](#)

#### Co-Drivers (IDs)

None

#### Trailers

None

#### Shipments

652512, SID

### Log Events

[Delete](#) [Change Vehicle](#) [New Status Change](#) [New Exception](#)

Hide history  Allow multi-select

Type / Status	Seq ID	Origin	Record Status	Start	End	Details	Vehicle ID	Distance Driven	Vehicle Miles	Engine Hrs	Conflicts
SB	48	Driver	Active	9/12/2017 3:01 PM	11:33 AM	Milwaukee, WI	6026221		N/A	N/A	
[9/18/2017 1:48 PM CDT Driver One (sgoss)] Malfunction											
<a href="#">+</a> <a href="#">-</a> <a href="#">🗑️</a> ON	39	Driver	Active	11:33 AM	1:00 PM	Minnetonka, MN			N/A	N/A	
<a href="#">+</a> <a href="#">-</a> <a href="#">🗑️</a> OFF	40	Driver	Active	1:00 PM	2:12 PM	St. Cloud, MN			N/A	N/A	
Driver Log Certification	46	Driver	Active	1:29 PM	-	Certified log date 9/10/2017			N/A	N/A	
Driver Log Certification	49	Driver	Active	1:48 PM	-	Certified log date 9/12/2017			N/A	N/A	
<a href="#">+</a> <a href="#">-</a> <a href="#">🗑️</a> ON	41	Driver	Active	2:12 PM	3:36 PM	MINNEAPOLIS, MN			N/A	N/A	
<a href="#">+</a> <a href="#">-</a> <a href="#">🗑️</a> OFF	43	Driver	Active	3:36 PM	9/19/2017 10:32 AM	minneapolis, GA			N/A	N/A	
Driver Log Certification	42	Driver	Active	3:37 PM	-	Certified log date 9/11/2017			N/A	N/A	

If a PeopleNet Fleet Manager user has proposed an edit to your log, you will see the proposed edit in the **Log Events** section of the page. You can accept or reject it by clicking the green thumbs-up or red thumbs-down icon. You can also click **View Proposed** (above the graph grid) to view the grid as it would be if you accepted the proposed edits.

		ON	44	Other User	Inactive - Requested (edit)	8:45 AM	-	Coralville, IA	3100B835A7E5A300	N/A	N/A
[6/9/2017 4:01 PM CDT ISE Admin (iseadmin)] GPS failure											

Any proposed, accepted, or rejected edits to the log can be seen in the event details. If the driver accepts a proposed edit, the original event will be displayed with a status of *Inactive - Changed*. Use the **+** icon to add annotations to a log event if needed.

			43	Other User	Active	8:35 AM	8:45 AM	Coralville, IA	3100B835A7E5A300	10 mi (16 km)	0 mi E	0 E
[6/7/2017 9:03 AM CDT ISE Admin (iseadmin)] Correction to drivers log [6/7/2017 9:03 AM CDT System] AOBRD applied												
			43	Automatic	Inactive - Changed	8:35 AM	8:45 AM	Location Pending	3100B835A7E5A300	10 mi (16 km)	0 mi E	0 E
[6/7/2017 9:03 AM CDT System] AOBRD applied												

For more information and instructions on how to edit logs, click **Help**.

## Print Multiple Logs

**Print Multiple Logs** allows you to generate a PDF or CSV file which you can then save, print, or email. Select the date range you wish to print, then click **Print** to export a PDF file or **Export** to export a CSV spreadsheet.

[Help](#)   [Sign Out](#)  
 QA Test Org / Driver Five  
 v9.1.4



### Print Multiple Logs

[HOME](#)   [HOS](#) >   [SETTINGS](#) >

**Note:** Please limit your selection to 180 log days at once, e.g., 180 days for one driver, or 90 days for two.

Dates: 8/14/2019 to 8/21/2019

[Print](#)   [Export](#)

## Uncertified Logs Report

The **Uncertified Logs Report** allows the driver to identify logs that require certification. ELD regulations require that drivers certify their logs immediately after the final entry has been made for the 24-hour period. If edits are necessary after the driver certifies the log, the driver must recertify the updated records. The driver can certify their logs on the device or through the driver portal.

The driver portal homepage displays a count of all uncertified logs. Click the box or navigate to **Uncertified Logs Report** under the **HOS** menu to view the individual dates that need to be certified. Click a date to be taken to the log for that day.

The screenshot shows the PeopleNet web application interface. At the top right, there are links for 'Help' and 'Sign Out', and the text 'QATestOrg / Driver Five v9.1.4'. The main header area includes the PeopleNet logo and the title 'Uncertified Logs Report'. Below this is a navigation bar with 'HOME', 'HOS', and 'SETTINGS'. A date range selector shows 'Dates: 2/21/2019 to 8/21/2019'. A 'View' button is present. The main content area displays 'Uncertified Logs for Five, Driver from 2/21/2019 to 8/21/2019' with a 'Count: 14'. A list of dates is shown in a grid format:

06/13/2018	06/18/2018	06/29/2018
06/14/2018	06/21/2018	06/30/2018
06/15/2018	06/26/2018	07/01/2018
06/16/2018	06/27/2018	07/02/2018
06/17/2018	06/28/2018	

**For ELD compliance, drivers must certify their previous log(s) daily. The device will notify them of uncertified logs during sign in and prompt them through certifying any uncertified logs during sign out.**

## SETTINGS

Under **Settings, User Preferences** allows you to set your PeopleNet Fleet Manager ELD preferences or change your password.

### Maximum Rows Per Page

This preference limits the number of rows shown in ELD screens that can be displayed in a table at one time without paging. Choose from 10, 20, 50, or 100.

### Time Zone for Reports

This preference sets the time zone to be used for reports that aren't specifically based on the time zone of your driver log.

### Name Style for Reports

This preference determines how your name is displayed in the web application and in printed reports. Choose from the following:

**Name Only** - Display your first and last name

**Name with ID\*** - Display your first and last name followed by your ID

\*If you choose **Name with ID**, use caution to protect your ID from unauthorized distribution.

## Units for Distance/Odometer

This preference sets the units for displaying and entering odometer readings and for displaying distance traveled. Choose from miles or kilometers.

## Change My Password

This button allows you to change your password. You will need to know your current password in order to change it. Contact your administrator to have your password reset if you do not know your current password

[Help](#) [Sign Out](#)



### User Preferences

[HOME](#) [HOS](#) [SETTINGS](#)

[Save](#) [Cancel](#)

**Maximum rows per page:**

**Time zone for reports:**   **Adjust for DST**

**Name style for reports:**

**Units for distance/odometer:**

[Change My Password...](#)

#### UNITED STATES

Trimble Transportation  
4400 Baker Road  
Minnetonka  
MN 55343-8684

#### CANADA

Trimble Transportation  
1100 Burloak Drive  
Suite 300 Burlington  
Ontario Canada L71 6B2

#### CONTACT

Phone: +1-866-914-5299  
Fax: +1-952-908-6129  
Email: [tm\\_information@trimble.com](mailto:tm_information@trimble.com)  
Web: [www.transportation.trimble.com](http://www.transportation.trimble.com)